


Venstar Indoor Temperature Sensor ACC0401



STANDARD FEATURES:

- The remote temperature sensor with override button measures indoor air temperature at a location separate from the thermostat.
- This sensor is a three-wire, digital sensor. On commercial thermostats, the sensors override button is used to change the thermostat from unoccupied to occupied mode to provide after hours heating or cooling.
- Acceptable Wire Types: CAT5, CAT5e, or CAT6 network communication cable, unshielded with 4 twisted pairs of 24 gage solid wire
- Maximum distance between sensor and thermostat using 24 gauge wire — 250 ft

MODEL:	ACC0401	QUANTITY:		DATE:		
JOB NAME:						
LOCATION:						
BUYER:				BUYER P.O.#:		
ENGINEER:						