

## UPDATE INSTRUCTIONS



In order to update the Venstar T5800/T6800 TouchScreen Thermostat with **VR 2.03\*** or earlier you will need to have the following items:

1. A computer with an active internet connection
2. A blank SD card
3. An SD card reader (most computers have this built-in)
4. An installed and powered T5800/T6800

*\*Thermostats with firmware 2.04 or later may download new firmware via a wi-fi connection using the ACC0454 Skyport Wi-Fi Key.*

The first step in updating your thermostat is to install the ColorTouch Assistant software on your computer. Please navigate to <http://venstar.com/> and click the **“Click here to download the latest Skyport ColorTouch Firmware”** link:



Click the **“Click here”** link. If your computer has trouble downloading the program, please note that the Manual Install option is available.

When the ColorTouch Assistant web page loads, click the **“Download & Install”** button.



### ColorTouch Firmware Upgrade

**Option 1: ColorTouch Assistant (preferred)**

It is recommended to use ColorTouch Assistant software to initialize an SD card and upgrade to the latest firmware.

Besides upgrading to the latest firmware, with ColorTouch Assistant you can import and edit your photos from a drive on your computer, prepare them for use as the thermostat's screen saver, or choose a photo for a custom wallpaper background. ColorTouch Assistant allows you to configure your time period schedule and adjust your thermostat's installation settings from the comfort of your laptop or desktop computer.


[Click here](#) to download ColorTouch Assistant software.

**Option 2: Manual Download**


You can also initialize an SD card manually. Please follow the instructions below to quickly initialize an SD card for upgrading ColorTouch firmware to the latest version.

1. [Click here](#) to download the latest Skyport compatible ColorTouch firmware
2. Unzip the downloaded file contents into an empty SD card
3. Use the SD card with your ColorTouch to upgrade to the latest firmware

Click the “Install Now” button. If your computer has trouble downloading the program, please note that the Manual Install option is available.



In the pop-up dialog, click the Open button. The CTA program should launch and be installed on your computer.




Now insert your blank SD card into the computer card reader. If your SD card was successfully recognized by the program you will see an icon at the bottom right of the TSA as seen here.



To download the latest firmware onto your SD card, click on the “New Thermostat Configuration” button and select the T5800 or T6800 model.




Click the “Save to SD” button to automatically download a blank file to your SD card with the new firmware for your thermostat.




When the “Saving to SD” dialog appears, select the SD card and click “OK”.

If the Export is successful the “Export Confirmation” dialog will appear. Click “OK” and eject your SD card.




To download the latest firmware onto your T5800/T6800 thermostat, insert the SD card with the new firmware into the SD card slot on the side of the thermostat.


Now press the MENU button on the bottom right and navigate to "Page 2 of 2" by pressing the Down Arrow key.



Click the SETTINGS button and navigate to the bottom of the list to select the INSTALLATION SETTINGS button.



Finally, navigate to the bottom of the Installation Settings menu and click the UPGRADE FIRMWARE BUTTON.



A new window will launch asking you to confirm that you wish to upgrade the firmware. Click YES and the thermostat will enter the updating process.

