

LOCKING COVER FOR COMMERCIAL THERMOSTATS

1 KEYPAD LOCK

To prevent the use of the thermostat after the locking cover has been installed:

- Press and hold the MODE button.
- While holding the Mode button down, press the WARMER and COOLER buttons simultaneously.
- The  icon will appear on the display
- The thermostat is unlocked by performing the same procedure as outlined above.

2 SECURITY LEVELS

On commercial thermostats the Locking Cover enhances the use of Security Levels. The Security Levels allow limited button function, which is determined by which Security Level is selected in the setup of the thermostat.

- Security Level “0” is no security, however, as outlined above, the keypad may be locked.
- Security Level “1” allows for set point limiting (maximum heat & minimum cool set points).
- Security Level “2” allows for set point limiting and locks the thermostat into Program On mode. This is normally used to keep the time period program running at all times.
- Security Level “3” locks out all button operation except for the OVERRIDE button. Security Level 3 is used so that no set point changes may be made and the time period program is running at all times. Additionally, during programmed, unoccupied periods, a press of the OVERRIDE button will force the thermostat into Occupied I comfort settings, temporarily. During programmed, occupied periods, a press of the OVERRIDE button will force the thermostat into Unoccupied I settings.
- Security Levels are set in the setup section of the thermostat. Please consult the Owners Manual of the thermostat for further instruction.

3 INSTALLATION

Mount the thermostat on the wall and set the desired security level and/or lock the buttons BEFORE attaching the Locking Cover. To attach the cover ‘hook’ the top edge of the Locking Cover behind the top of the thermostat, then ‘hinge’ closed the Locking Cover over the thermostat and turn the key 90 degrees.

